



Note: The $\varnothing 30$ holes are for access, we recommend using M10 anchor bolts that will fit into the $\varnothing 16$ holes.